


MG UPS SYSTEMS, INC. CLAIMS PROPRIETARY RIGHTS IN THE MATERIAL DISCLOSED HEREIN. THIS DOCUMENT IS ISSUED FOR ENGINEERING INFORMATION ONLY. IT MAY NOT BE DISCLOSED TO OTHERS NOR MAY IT BE USED FOR MANUFACTURING PURPOSES WITHOUT WRITTEN PERMISSION FROM MG UPS SYSTEMS, INC.

RECOMMENDED AISLE SPACE = 30.00 (762)  
 DOOR SWING = 28.58 (870) MIN (110" MAX)



DWG NO. 90-160080-05


SH 1 REV. B01

REVISIONS			
REV	DESCRIPTION	DATE	APPROVED
A00	NEW RELEASE PER ECN 287-02	4/8/97	B. WILLIAMS
B00	REVISED PER ECN 288-22	10/6/97	B. WILLIAMS
B01	REVISED PER ECN-022247	10/6/01	JM


- NOTES: UNLESS OTHERWISE SPECIFIED.
1. DIMENSION FORMAT IS INCHES (MM).
  2. ALL DIMENSIONS ARE TO THE OUTSIDE EDGE OF THE CABINET EXCLUDING DOOR LOCKS AND ALL HARDWARE.
  3. COLOR: MGE LIGHT GRAY (RAL 9002)
  4. OPERATING TEMPERATURE: 32°F(0°C) TO 86°F(30°C).
  5. THE AUXILIARY CABINET MUST BE INSTALLED AND ALIGNED TO THE LEFT SIDE OF THE COMET UPS CABINET.
  6. MGE WILL PROVIDE ALL POWER CABLES BETWEEN THE UPS CABINET AND THE AUXILIARY CABINET. IT IS THE RESPONSIBILITY OF THE CUSTOMER TO CONNECT THE CABLES.
  7. A PHILLIPS TYPE SCREWDRIVER IS REQUIRED TO REMOVE INSIDE PANELS OR PLATES.
  8. MAXIMUM HEAT GENERATED: 4700 BTU/HR
  9. APPROXIMATE WEIGHT: 110LBS/49.9KGS.
  10. THIS DRAWING SHOULD BE USED IN CONJUNCTION WITH THE SYSTEM INSTALLATION DRAWINGS.

UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN INCHES TOLERANCES ARE:		[DIMENSIONS]	
FINISH	MATERIAL	APPROVALS	DATE
		DRAWN: BKH/DJL/BI	04-08-97
		CHECKED: B. WILLIAMS	4/8/97
		ISSUED: B. WILLIAMS	4/8/97
<b>MG E</b> MGE UPS Systems, Inc. 11500 Spring Avenue Cedar Rapids, IA 52403 U.S.A.		INSTALLATION DRAWING AUXILIARY CABINET COMET (40/50/65/80KVA)	
SCALE	DWG NO.	REV.	SHEET
1:1	90-160080-05	B01	1 OF 2

DO NOT SCALE DRAWING




TOP ENTRY CONDUIT PLATE (26.75" CABINET)



BOTTOM ENTRY CONDUIT PLATE

BYPASS INPUT  
PWR. DIST. BLK.  
(FOR TOP DIELE ACCESS)



FRONT VIEW  
(PANEL REMOVED)

- BOTTOM CONDUIT INSTALLATION INSTRUCTIONS**
1. REMOVE MOUNTING SCREWS FROM CONDUIT PLATE.
  2. PUNCH OUT REQUIRED CONDUIT HOLES.
  3. REPLACE CONDUIT PLATE ON UNIT WITH MOUNTING SCREWS BEFORE INSTALLING CONDUITS.

- TOP CONDUIT INSTALLATION INSTRUCTIONS**
1. REMOVE MOUNTING SCREWS FROM PLATES.
  2. PUNCH OUT REQUIRED CONDUIT HOLES.
  3. REPLACE CONDUIT PLATE ON UNIT WITH MOUNTING SCREWS BEFORE INSTALLING CONDUITS.
  4. REMOVE THE SIDE PLATE AND CONNECT THE POWER CABLES TO THE POWER DISTRIBUTION BLOCK.

SIZE	SCALE	DWG. NO.	REV.
B	NONE	90-160080-05	B01
SHEET 2 OF 2			